

LumiPlus CONTROL MOTION



59125E201



COLOR

Central Display / Indicateur Central
Indicador Central / Indicatore Centrale
Display Angezeigt / Indicador Central



REFRESH



SEQUENCE



SPEED +/-



ON/OFF

ENGLISH

CHANGE OF FREQUENCY / REMOTE CONTROL CHANNEL

Attention: Before programming the flood lamp, turn the power supply OFF.

Programming process:

1. Connect the flood lamp to the power supply and turn the remote control on (you have one minute to finish the process or you will have to start again).
2. Hold down the refresh button  for 15 seconds on the remote control, until number 1 on the remote control is switched on (or the channel that you have configured from 1 to 4).
 - 2.1 Stop pressing the refresh button.
 - 2.2 Press + or – to change channel (there are 4 different channels).
 - 2.3 Press the refresh button again to save the channel.
 - 2.4 Check that the projector is responding to remote control orders.

If point 2.4 works, you have successfully changed to the new channel. If the lamp does not respond, start again from point 1.

LumiPlus Control Motion is only compatible with the Lumiplus PAR56 Wireless range.

FRANÇAIS

CHANGEMENT DE FRÉQUENCE / CANAL DE CONTRÔLE À DISTANCE

Attention: Avant de commencer la programmation, veuillez vous assurer que le projecteur NE reçoit PAS de tension.

Processus de programmation:

1. Connectez le projecteur au réseau et allumez la télécommande (vous disposez d'une minute pour terminer le processus, sinon vous devrez recommencer depuis le début).
2. Appuyez pendant 15 secondes sur la touche refresh  de la télécommande jusqu'à ce que le numéro 1 de la télécommande (ou du canal que vous avez configuré de 1 à 4) s'allume.
 - 2.1 Arrêtez d'appuyer sur la touche refresh.
 - 2.2 Appuyez sur + ou – pour changer de canal (il y a 4 canaux différents).
 - 2.3 Appuyez à nouveau sur la touche refresh pour maintenir le canal.
 - 2.4 Vérifiez que le projecteur répond aux ordres de la télécommande.

Si le point 2.4 fonctionne, vous avez réussi à aller sur le nouveau canal. Si la lampe ne répond pas, recommencez depuis le point 1.

LumiPlus Control Motion est uniquement compatible avec la gamme Lumiplus Wireless.